



# DNH

HEAD OFFICE, NORWAY  
DNH AS

Phone..... + 47 35 98 56 00  
Fax..... + 47 35 98 56 10  
E-mail..... dnh@dnh.no  
Web-Site..... www.dnh.no

ENGLAND  
DNH WW Ltd

Phone..... + 44 1908 275 000  
Fax..... + 44 1908 275 100  
E-mail..... dnh@dnh.co.uk

GERMANY  
DNH GmbH


Phone... + 49 040 6569 30-0  
Fax..... + 49 040 6569 30-30  
E-mail..... dnh@dnh.de

## BAREEx-36(T)


USA  
DNH Speakers Inc

Phone..... + 1 484 494 5790  
Fax..... + 1 484 494 5793  
E-mail..... dnh@dnhspeakers.com

ISO 9001 CERTIFIED



Certified by/ Certification code / Number : NEMKO / EEx de IIB+H2 T6 Gb / Nemko10ATEX1058X  
IECEx NEM 11.0031X



Specifications	
Material / Color	Aluminum / anodized
Mounting	4 screws
Termination	e-chamber, screw terminals
Weight w/transformer	2,35 kg
IP-rating	67
Max. / min. amb. temp	40°C / -20°C
Rated / max. power	6 W / 6 W
SPL 1W/1m	85 dB
SPL rated power	92 dB
Effective freq. range	180 – 15000 Hz
Dispersion (-6dB) 1kHz / 4kHz	NA
Directivity factor, Q	NA
Options	Impedances, colors, labels

### Installation, Operation and Maintenance Procedures

- Rotate grill counterclockwise to remove it.
- Remove the terminal lid by one screw.
- Lead cable through cable gland.
- Fasten loudspeaker to wall or ceiling with 4 screws (max. Ø 4,2mm).
- Terminate the cable in the screw terminal (select required tapping).
- Fasten the terminal lid by one screw with a torque of 1 – 1,5 Nm to assure the IP rating.
- Use only certified/specified cable glands and blanking plugs.
- Ex-loudspeakers must be earthed correctly using the specially marked screws.
- For optimum performance, always use the correct voltage / power and operate within the frequency limits as stated.
- Do not open loudspeaker when energized.
- This loudspeaker is supplied with a 2 year warranty against defective workmanship.

DNH reserves the right to alter specifications without notice

